




Hold the locking body with the marking facing front and insert the cable in the dead-end-hole, until the coloured end appears in the window securing that the cable has been applied correctly.

| CETE | |
|---------|--|
| 0000000 | |


Pull the cable to ensure, that it is properly locked.



Lead the cable through the device to be sealed.

Bend the cable 180° and insert the cable in the right hole until it has passed through the locking body.

Pull the cable until it is tight to ensure proper sealing.



Pull the locking body to ensure that the seal is properly locked.

www.oneseal.com